



Maytag Commercial Maytag DG30CT Dryer Parts Parts Diagram 08 - CT CONTROL CENTER & COMPONENTS SERIES 01

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	202894			Solenoid For Relay Assembly
002	NLA		Not Available	CAGE NUT
003	212220	213501		Screw, No.6-20 X 1-1/8 Inch
004	212949	22001866		Screw, Relay
005	212950	M0227520		Screw-Tc No.6-32 X 13/16", Preform SwiTch
006	212951			Screw, No.6-32 X 1/4 Inch
007	Y303787		Not Available	SWITCH FOR RELAY
008	NLA		Not Available	CLIP - ACTUATOR TO CABINET
009	Y330083		Not Available	CONTROL, TEMPERATURE
010	Y330092			Terminal Block
011	NLA		Not Available	FRONT PANEL-WHITE
012	NLA		Not Available	WIRE HARNESS
013	NLA		Not Available	TIMER W/KNOB AND PIN
014	Y330147			Part Not Used

015	NLA		Not Available	VAULT ASSEMBLY
016	NLA		Not Available	SCREW - BRACKET TO VAULT
017	331012	400022-1		Screw
018	331014	8281196		Screw
019	331026	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
020	331032	61002031		Screw, Handle
021	331036			Washer-Front Panel Screws
022	331061			Knob For Temperature Contro
023	NLA		Not Available	MOUNTING PLATE-TEMP.CONTROL
024	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
025	NLA		Not Available	SPACER - TEMP CONTROL COVER
026	NLA		Not Available	BRACKET FOR TIMER MOUNTING
027	NLA		Not Available	SCREW-TEMP CONTROL LEVER
028	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
029	331151			Lever-Temperature Control
030	NLA		Not Available	TWIN FASTENER WITH SCREWS
031	NLA		Not Available	SPRING LEVER FOR RELAY
032	NLA		Not Available	RELAY BRACKET

