


# Maytag DG30CT 11 - LINT SCREEN-LOWER FRONT



Maytag [Commercial Maytag DG30CT Dryer Parts](#) Parts Diagram 11 - LINT SCREEN-LOWER FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y055980</a>			Hi-Temp Adhesive, 2 Oz Tube
002	<a href="#">210866</a>			Nut, Twin Speed
003	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
004	NLA		Not Available	LEVELING LEG
005	Y330071		Not Available	IMPELLER FOR BLOWER
006	<a href="#">Y330078</a>			Cool-Down Bypass Switch
007	<a href="#">Y330086</a>			Lint Screen With Frame
008	NLA		Not Available	WING NUT - LINT HOOD TO CAB
009	NLA		Not Available	WASHER-LINT HOOD TO CABINET
010	331031		Not Available	SET SCREW FOR IMPELLER
011	331032	<a href="#">61002031</a>		Screw, Handle
012	<a href="#">331036</a>			Washer-Front Panel Screws
013	331048		Not Available	COVER FOR BLOWER IMPELLER
014	NLA		Not Available	SHIELD FOR DAMPER SWITCH

