


Maytag DG30MC1 06 - MAIN DOOR ASSEMBLY (LATCH TYPE DG30/50)



Maytag [Commercial Maytag DG30MC1 Dryer Parts](#) Parts Diagram 06 - MAIN DOOR ASSEMBLY (LATCH TYPE DG30/50)

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|----------------------|---------------------------|---------------|--|
| NI | W10124350 | | Not Available | ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000 |
| 001 | A800287 | | Not Available | DOOR ASSY (ALM) (INCL 1,5,6, & 7) |
| " | A800288 | | Not Available | DOOR ASSEMBLY (WHT) (INCL. ILLUS. No.1 & 5 THRU 9) |
| 002 | A103050 | | Not Available | HINGE, DOOR |
| 003 | A150410 | MC80MD | | Elmntsurf |
| 004 | A152014 | 152014 | | 1 4-20 Ser |
| 005 | A102350 | W10149210 | | 68 1 2 Do |
| 006 | A102210 | 102210 | | 20 7 16 D |
| " | A170730 | 170730 | | 10.3 Oz Cl |
| 007 | A150431 | 150431 | | 10x7 16 D |
| " | A404500 | WB22X55 | | Switch |
| " | A404502 | 404502 | | White 0.6 |