


Maytag DG30PN1 04 - MAIN DOOR ASSEMBLY (LATCH TYPE DG30/50)



Maytag [Commercial Maytag DG30PN1 Dryer Parts](#) Parts Diagram 04 - MAIN DOOR ASSEMBLY (LATCH TYPE DG30/50)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A800287		Not Available	DOOR ASSY (ALM) (INCL 1,5,6, & 7)
"	A800288		Not Available	DOOR ASSEMBLY (WHT) (INCL. ILLUS. No.1 & 5 THRU 9)
002	A103050		Not Available	HINGE, DOOR
003	A150410	MC80MD		Elmntsurf
004	A152014	152014		1 4-20 Ser
005	A102350	W10149210		68 1 2 Do
006	A102210	102210		20 7 16 D
"	A170730	170730		10.3 Oz Cl
007	A150431	150431		10x7 16 D
"	A404500	WB22X55		Switch
"	A404502	404502		White 0.6