


Maytag DG31CA 06 - DOOR SWITCH, TEMP CNTRL, & TERMINAL BLOCK

MODEL DG31CA-CM-CT

DOOR SWITCH, TEMPERATURE CONTROL & TERMINAL BLOCK



Maytag [Commercial Maytag DG31CA Dryer Parts](#) Parts Diagram 06 - DOOR SWTCH, TEMP CNTRL, & TERMINAL BLOCK

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052749	62739		Nut, Lock
002	NLA		Not Available	LOCK WASHER, 3/8 X 1/16
003	210866			Nut, Twin Speed
004	212220	213501		Screw, No.6-20 X 1-1/8 Inch
005	212951			Screw, No.6-32 X 1/4 Inch
006	NLA		Not Available	CLIP - ACTUATOR TO CABINET
007	Y330077			Door Switch
008	Y330078			Cool-Down Bypass Switch
009	Y330083		Not Available	CONTROL, TEMPERATURE
010	Y330087			Drum Assembly Complete
011	Y330092			Terminal Block
012	NLA		Not Available	FRONT PANEL-WHITE
013	NLA		Not Available	FRONT PANEL-ALMOND
014	NLA		Not Available	FRONT PANEL-HARVEST WHEAT

015	Y330100		Not Available	COIN BOX ASSEMBLY
016	Y330147			Part Not Used
017	NLA		Not Available	VAULT ASSEMBLY
018	NLA		Not Available	SCREW - BRACKET TO VAULT
019	331012	400022-1		Screw
020	331014	8281196		Screw
021	331026	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
022	NLA		Not Available	SQUARE WASHER FOR DRUM ROD
023	331058			Grommet-Temp. Control Tubin
024	331061			Knob For Temperature Contro
025	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
026	NLA		Not Available	DRUM ROD
027	NLA		Not Available	ACTUATOR FOR DOOR SWITCH
028	NLA		Not Available	SCREW-TEMP CONTROL LEVER
029	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
030	331151			Lever-Temperature Control
031	NLA		Not Available	NUT FOR CONDUIT
032	331230			Clip
033	NLA		Not Available	TWIN FASTENER WITH SCREWS

