


Maytag DG31CM 01 - FRONT VIEW-DOOR OPEN



Maytag Commercial Maytag DG31CM Dryer Parts Parts Diagram 01 - FRONT VIEW-DOOR OPEN
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	GULMITE WRENCH No.8
002	NLA		Not Available	SCREW, No.5-40 X 3/8
003	213966	3400014		Screw
004	Y330064			Pilot Light
005	NLA		Not Available	LEVELING LEG
006	Y330077			Door Switch
007	Y330079		Not Available	SWITCH, PUSH-TO-START
008	Y330080		Not Available	SPIDER & SHAFT ASSEMBLY
009	330081			Timer - CA 60 Minutes
010	Y330087			Drum Assembly Complete
011	NLA		Not Available	FRONT PANEL-WHITE
012	NLA		Not Available	FRONT PANEL-ALMOND
013	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
014	NLA		Not Available	HINGE FOR DOOR
015	Y330102			FRONT PANEL-WHITE

016	NLA		Not Available	FRONT PANEL-ALMOND
017	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
018	Y330103			Lock
019	NLA		Not Available	TIMER ACCUMULATOR - CM
020	NLA		Not Available	FRONT PANEL-WHITE
021	330108L		Not Available	FRONT PANEL-ALMOND
022	330108M		Not Available	FRONT PANEL-HARVEST WHEAT
023	NLA		Not Available	PART NOT USED
024	NLA		Not Available	MOUNTING PLATE (ACCUMULATOR)
025	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
026	Y330147			Part Not Used
027	NLA		Not Available	HANDLE & PIN KIT
028	NLA		Not Available	DOOR-WHITE
029	NLA		Not Available	DOOR-ALMOND
030	NLA		Not Available	DOOR-HARVEST WHEAT
031	Y330192		Not Available	SWITCH, PUSH TO START
032	NLA		Not Available	DOOR-WHITE
033	NLA		Not Available	DOOR-ALMOND
034	NLA		Not Available	DOOR-HARVEST WHEAT
035	331014	8281196		Screw
036	NLA		Not Available	SCREW - HANDLE TO DOOR
037	331032	61002031		Screw, Handle
038	331036			Washer-Front Panel Screws
039	331041			Button-Push-To-Start Switch
040	331061			Knob For Temperature Contro
041	331064		Not Available	MAGNET FOR DOOR HANDLE
042	331071		Not Available	STRIKE PLATE FOR DOOR
043	331083		Not Available	SUPPORT FOR DOOR GLASS
044	NLA		Not Available	ACTUATOR FOR DOOR SWITCH
045	NLA		Not Available	TRIM STRIP-LOWER FRONT PANE
046	NLA		Not Available	TRIM BAR FOR UPPER PANEL
047	NLA		Not Available	POLE BLOCK FOR DOOR MAGNET
048	331101		Not Available	BEZEL FOR TIMER-ACCUMULATOR
049	NLA		Not Available	PART NOT USED
050	NLA		Not Available	INSTRUCTION PLATE - CM
051	NLA		Not Available	HINGE RIVET
052	NLA		Not Available	DOWEL PIN FOR HANDLE
053	NLA		Not Available	PART NOT USED
054	NLA		Not Available	SCREW-TEMP CONTROL LEVER
055	331151			Lever-Temperature Control
056	331165			Gasket For Door Glass
057	331166			Glass For Door
058	331167			Gasket For Door-Outer
059	331185			Hinge Pin For Door
060	911852	486009		Lockwasher