


CA TIMER, CM TIMER ACCUMULATOR & CT TICKET CONTROL



Copyright 1978 THE MAYTAG COMPANY • Newton, Iowa • Printed in U.S.A.

Maytag [Commercial Maytag DG32CA Dryer Parts](#) Parts Diagram 03 - CA & CM TIMER ACCUMULATOR, CT TICKET
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	TOOL TO ADJUST TIMING SWITCH
002	NLA		Not Available	SCREW, No.5-40 X 3/8
003	NLA		Not Available	TICKET RECEIVER ASSEMBLY
004	NLA		Not Available	FRONT PLATE, TICKET CONTROL
005	Y330064			Pilot Light
006	Y330079		Not Available	SWITCH, PUSH-TO-START
007	330081			Timer - CA 60 Minutes
008	Y330082	330081		Timer - CA 60 Minutes
009	NLA		Not Available	TIMER ACCUMULATOR - CM
010	NLA		Not Available	FRONT PANEL (WHT)
011	NLA		Not Available	MOUNTING PLATE (ACCUMULATOR)
012	Y330145		Not Available	CONTA ACCUMULATOR ASSEMBLY
013	330184			Timer Accumulator-25

014	Y330192	Not Available	SWITCH, PUSH TO START
015	331014	8281196	Screw
016	331032	61002031	Screw, Handle
017	331036		Washer-Front Panel Screws
018	331041		Button-Push-To-Start Switch
019	NLA	Not Available	TIMER DIAL - CA 60 MINUTES
020	331061		Knob For Temperature Contro
021	NLA	Not Available	KNOB, TIMER
022	NLA	Not Available	MOUNTING PLATE, TIMER
023	NLA	Not Available	TRIM BAR, UPPER PANEL
024	331101	Not Available	BEZEL FOR TIMER-ACCUMULATOR
025	NLA	Not Available	INSTRUCTION PLATE (CA)
026	NLA	Not Available	INSTRUCTION PLATE - CM
027	NLA	Not Available	INSTRUCTION PLATE-CT
028	NLA	Not Available	MOUNTING PLATE-TICKET CONT
029	NLA	Not Available	INSTRUCT LABEL - SINGLE COI
030	331151		Lever-Temperature Control
031		Not Available	

