


# Maytag DG32CM 10 - BURNER VALVE & CONTROLS-UPPER COMP.



Maytag Commercial Maytag DG32CM Dryer Parts Parts Diagram 10 - BURNER VALVE & CONTROLS-UPPER COMP.  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">210866</a>			Nut, Twin Speed
002	212220	<a href="#">213501</a>		Screw, No.6-20 X 1-1/8 Inch
003	<a href="#">Y330078</a>			Cool-Down Bypass Switch
004	NLA		Not Available	TWIN FASTENER W/SCREWS
005	<a href="#">212951</a>			Screw, No.6-32 X 1/4 Inch
006	<a href="#">Y330064</a>			Pilot Light
007	NLA		Not Available	BURNER, MAIN
008	<a href="#">Y330073</a>			Valve, Shut-Off
009	NLA		Not Available	MANIFOLD, MAIN BURNER
010	Y330079		Not Available	SWITCH, PUSH-TO-START
011	<a href="#">330081</a>			Timer - CA 60 Minutes
012	Y330082	<a href="#">330081</a>		Timer - CA 60 Minutes
013	Y330083		Not Available	CONTROL, TEMPERATURE
014	<a href="#">Y330092</a>			Terminal Block
015	Y330096	<a href="#">Y330233</a>		Mounting Plt, Cm Timer Accum.

016	NLA		Not Available	FRONT PANEL (WHT)
017	NLA		Not Available	SUPPORT, BURNERS
018	Y330100		Not Available	COIN BOX ASSEMBLY
019	<a href="#">Y330103</a>			Lock
020	NLA		Not Available	LOCK
021	NLA		Not Available	TIMER ACCUMULATOR - CM
022	NLA		Not Available	FRONT PANEL (WHT)
023	NLA		Not Available	PILOT ORIFICE - LPG
024	NLA		Not Available	PILOT ORIFICE - NAT
025	NLA		Not Available	MOUNTING PLATE (ACCUMULATOR)
026	NLA		Not Available	VAULT ASSEMBLY
027	<a href="#">Y330174</a>			Electronic Ignition Control
028	<a href="#">Y330175</a>			Pilot Burner
029	<a href="#">Y330176</a>			Sensing Probe
030	<a href="#">Y330177</a>			Burner Solenoid-Main
031	330181		Not Available	CONVERSION KIT-NAT. TO LPG
032	<a href="#">Y330182</a>			Burner Solenoid-Pilot
033	330183		Not Available	TRANSFORMER
034	<a href="#">330184</a>			Timer Accumulator-25
035	NLA		Not Available	PILOT FILTER
036	Y330192		Not Available	SWITCH, PUSH TO START
037	NLA		Not Available	PILOT ORIFICE - NAT
038	<a href="#">Y330195</a>			Pilot Orifice - LPG
039	Y330201		Not Available	HIGH LIMIT THERMOSTAT
040	331003	<a href="#">489483</a>		Screw 10-32 X 1/2
041	NLA		Not Available	SCREW, BRACKET (VAULT)
042	<a href="#">Y330206</a>			Wire For Sensing Probe
043	331009	<a href="#">400022-1</a>		Screw
044	331012	<a href="#">400022-1</a>		Screw
045	331013	<a href="#">Y0300830</a>		Screw No.10-32 X .375
046	331014	<a href="#">8281196</a>		Screw
047	NLA		Not Available	CABLE CLAMP
048	331026	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
049	331032	<a href="#">61002031</a>		Screw, Handle
050	<a href="#">331036</a>			Washer-Front Panel Screws
051	<a href="#">331041</a>			Button-Push-To-Start Switch
052	NLA		Not Available	BRACKET, GAS CONTROL
053	NLA		Not Available	RETAINER BRACKET, MAIN BURNER
054	331049		Not Available	VENTILATED COVER - HI- LIMIT
055	<a href="#">331058</a>			Grommet-Temp. Control Tubin
056	<a href="#">331061</a>			Knob For Temperature Contro
057	NLA		Not Available	ORIFICE, MAIN BURNER- NAT.
058	NLA		Not Available	ORIFICE, MAIN BURNER- BUTANE
059	NLA		Not Available	ORIFICE, MAIN BURNER (PROPANE)
060	NLA		Not Available	ORIFICE, MAIN BURNER
061	NLA		Not Available	MOUNTING PLATE, TIMER
062	NLA		Not Available	GAS SUPPLY LINE-28 1/2 INCH

063	NLA	Not Available	SPACER, HI-LIMIT (HOOD)
064	331084	Not Available	SUPPORT ROD FOR UPPER DOOR
065	331086	Not Available	SHIELD FOR PILOT BURNER
066	NLA	Not Available	PILOT SHIELD
067	331101	Not Available	BEZEL FOR TIMER-ACCUMULATOR
068	NLA	Not Available	HINGE RIVET
069	NLA	Not Available	SCREW-TEMP CONTROL LEVER
070	NLA	Not Available	BRACKET-TEMPERATURE CONTROL
071	<a href="#">331151</a>		Lever-Temperature Control
072	NLA	Not Available	BRACKET, MANIFOLD
073	NLA	Not Available	PILOT LINE
074	NLA	Not Available	NUT, CONDUIT
075	NLA	Not Available	LIGHTING INSTRUCTIONS LABEL
076	NLA	Not Available	SCREW, TERMINAL BLOCK (VAULT)

