


Maytag DG34CD 09 - LINT SCREEN-LOWER FRONT



Maytag Commercial Maytag DG34CD Dryer Parts Parts Diagram 09 - LINT SCREEN-LOWER FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052749	62739		Nut, Lock
002	Y054866	486009		Lockwasher
003	NLA		Not Available	LOCK WASHER, 3/8 X 1/16
004	Y055980			Hi-Temp Adhesive, 2 Oz Tube
005	210866			Nut, Twin Speed
006	212220	213501		Screw, No.6-20 X 1-1/8 Inch
007	NLA		Not Available	LEVELING LEG
008	Y330071		Not Available	IMPELLER FOR BLOWER
009	Y330078			Cool-Down Bypass Switch
010	Y330086			Lint Screen With Frame
011	NLA		Not Available	TEMPERATURE SENSOR ASSEMBLY
012	Y330280		Not Available	LINT HOOD ASSEMBLY
013	NLA		Not Available	WING NUT - LINT HOOD TO CAB
014	NLA		Not Available	WASHER-LINT HOOD TO CABINET

015	331031	Not Available	SET SCREW FOR IMPELLER
016	331032	61002031	Screw, Handle
017	331036		Washer-Front Panel Screws
018	NLA	Not Available	SQUARE WASHER FOR DRUM ROD
019	331053		Damper
020	331058		Grommet-Temp. Control Tubin
021	NLA	Not Available	HINGE PIN FOR DAMPER
022	NLA	Not Available	DRUM ROD
023	NLA	Not Available	SHIELD FOR DAMPER SWITCH
024	NLA	Not Available	TWIN FASTENER WITH SCREWS

the laundry company[®]

the laundry company[®]

the laundry company[®]