


Maytag DG75PN1 06 - FRONT PANEL ASSY. (MAGNET TYPE-DG50/75)



Maytag [Commercial Maytag DG75PN1 Dryer Parts](#) Parts Diagram 06 - FRONT PANEL ASSY. (MAGNET TYPE-DG50/75)

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|----------------------|---------------------------|---------------|---|
| 000 | W10124350 | | Not Available | ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000 |
| 001 | A800368 | W10147034 | | 25-50- RH- |
| " | A800371 | W10147035 | | 25-50-RH I |
| " | A800373 | W10147036 | | Ud-50-75 I |
| 002 | A313903 | | Not Available | STRIKER PAD (3 1/2" S.S.) |
| 003 | A154200 | 154200 | | 5 32 RIVE |
| 004 | A121405 | 121405 | | Rubber Gro |
| 005 | A150415 | | Not Available | SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2" PH. RD. HD.) |
| 006 | A137003 | 137003 | | Door Switch |
| 007 | A401551 | | Not Available | DOOR SWITCH SPACER/WASHER |
| 008 | A152003 | 152003 | | 3 8-32 X 1 |
| 009 | A313209 | W10146841 | | Main DR SW |
| " | A870010 | W10147883 | | Main Door |

