


Maytag DG75PN1 15 - UPSHOT BURNER ASSY/SAIL SWITCH/HI LIMIT



Maytag [Commercial Maytag DG75PN1 Dryer Parts](#) Parts Diagram 15 - UPSHOT BURNER ASSY/SAIL SWITCH/HI LIMIT

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A154004	154004		Tinnerman
002	A150415		Not Available	SCREW, CRIMPTITE (PH. RD.HD.) (No.10-16 X 1/2" PH. RD. HD.)
003	A802799	802799		Sail Sw.bo
004	A122200	122200		Sail Switch
005	A150303	150303		4 X 3 4 P
006	A105500	W10146641		Std Sail S
007	A319202	W10146866		Sail Switch
008	A154002	154002		1 8 Push O
009	A802800	802800		Sail Switch
"	A802801	802801		Sail Switch
010	A142704		Not Available	1/2"X5" NIPPLE
011	A141305		Not Available	BODY, UNION SHUT-OFF

012	A141303		Not Available	TAIL PIECE, 1/2" UNION
013	A401550		Not Available	TAIL PIECE COLLAR ONLY
014	A128927		Not Available	VALVE, GAS (REDUNDANT) (1/2" 24 VAC, NATURAL GAS)
015	A142506	142506		1 2 X 1 2
016	A142707	142707		1 2 X 1 1
017	A150300	5307527001		Switch
018	A318710	318710		75 gas Val
019	A143000	143000		1 2 X 3 4
020	A141153	141153		Letter Siz
021	A141150		Not Available	UPSHOT BURNER W/SHUTTER & SPREADER
022	A150301	150301		8-18 X 7
023	A318708	318708		75 Burner
024	A150300	5307527001		Switch
025	A150001	150001		6-32 X 1 2
026	A130401			HI-LIMIT (ONLY) (330 DEG.)
027	A151000	WH12X195		Switch Assembly
028	A318707		Not Available	HI-LIMIT MTG. BRKT. ONLY
029	A150300	5307527001		Switch
030	A804001	W10149277		75 Upshot
"	A809619		Not Available	NATURAL GAS BURNER ASSY. COMPLETE (NO ORIFICE)(INCL.
031	A874048	W10147902		75 Igri
032	A150300	5307527001		Switch
033	A128926		Not Available	MODULE, DSI ONLY
034	A150300	5307527001		Switch
"	A874042	874042		75 Upsho

the laundry company[®]

the laundry company[®]