

Maytag DGS30PC1 20 - HARNESS ASSEMBLY LISTING

WIRING HARNESS ASSEMBLY LISTING

Wire No.	Subassy. No.	Wire No.	Subassy. No.	Wire No.	Subassy. No.
1	842705	60	842713	131	842714
2	842704	61	842713	140	842733
3	842733	62	842704	141	842733
4	842733	63	842731	146	842733
5	842732	64	842731	200	842713
6	842732	65	842731	201	842731
7	842734	66	842727	202	842726
8	842735	69	842727	203	842726
10	842706	71	842733	204	842731
11	842729	72	842733	205	842713
12	842729	73	842712	206	842728
13	842729	74	842730	207	842728
14	842706	76	842705	208	842728
15	842706	81	842732	210	842713
16	842703	82	842732	211	842731
17	842703	83	842727	212	842727
18	842701	84	842731	213	842727
19	842701	86	842704	214	842731
20	842706	93	842734	215	842713
21	842729	94	842734	220	842704
22	842729	95	842735	221	842731
23	842729	96	842735	222	842726
24	842706	100	842715	223	842726
25	842706	101	842730	224	842731
26	842703	102	842699	225	842704
27	842703	103	842699	226	842713
28	842700	104	842730	227	842713
29	842700	105	842715	228	842703
30	842705	106	842714	229	842728
31	842705	107	842714	230	842728
32	842730	108	842714	231	842728
33	842730	110	842715	240	842732
40	842704	111	842730	241	842732
41	842704	112	842712	246	842732
42	842731	113	842712	247	842732
43	842731	114	842730	304	842700
44	842700	115	842715	305	842700
45	842700	120	842705	310	842718
46	842701	121	842730	311	842718
47	842701	122	842699	312	842718
50	842715	123	842699	313	842717
51	842715	124	842730	314	842717
52	842705	125	842705	315	842717
53	842730	126	842715	316	842703
54	842730	127	842715	317	842730
55	842730	128	842703	318	842731
56	842712	129	842714		
59	842712	130	842714		

Maytag [Commercial Maytag DGS30PC1 Dryer Parts](#) Parts Diagram 20 - HARNESS ASSEMBLY LISTING
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	W10124350		Not Available	HARNESS ASSEMBLY LISTING

