


Maytag GA26CD 06 - TUB



12

Maytag [Commercial Maytag GA26CD Washer Parts](#) Parts Diagram 06 - TUB
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	215532			Cap, Agitator
002	207119	207228		Agitator W/Lock Screw
003	206478		Not Available	SCREW & WASHER FOR AGITATOR
004	211100			Washer, Outer Tub
005	Y054867			Washer, Lock
006	204013	6-2040130		Tub Bearin
007	200824	6-2040130		Tub Bearin
008	211130			Bearing Liner, Tub Bearing
009	201537	6-2095720		Mounting S
010	204012	6-2095720		Mounting S
011	202521	6-2095720		Mounting S
012	211047	6-2110472		Nut- Clamp
013	Y0A4298	6-0A57420		Seal- Agitator
014	Y015667			Retaining Ring
015	Y015666			Washer, Retaining -
016	211210			Washer, Clamping Nut

017	207831		Not Available	TUB, INNER (W/PLUG)
018	205484			Tub, Outer Part Not Used
019	214739	596669		Clamp, Manifold
020	214725			Cap For Spout-Outer Tub
021	202574	3367052		Clamp, Hose
022	213045			Hose, Outer Tub Part Not Used
023	200900	616099		Clamp
024	211641			Clamp, 1-1/16"
025	200744	W10175939		Bolt
"	205254	W10175938		Bolt
026	212942	22001619		Tube, Water Level Switch
027	410296	596669		Clamp, Manifold
028	215980			Plug, Filter Hole

the laundry company[®]

the laundry company[®]

the laundry company[®]