


Maytag GDG18CT 07 - CT CONTROL CENTER COMPONENTS

DE-DG18CT CT CONTROL CENTER COMPONENTS



Maytag Commercial Maytag GDG18CT Dryer Parts Parts Diagram 07 - CT CONTROL CENTER COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
NI	Y201110		Not Available	CONNECTOR, WIRE (INDIC. LIGHT)
"	NLA		Not Available	JUMPER WIRE (BLACK)
"	202477	22003292		Control As
"	202479	A3167501		Lamp Oven, Int.
"	202509			Ticket Control Assembly
"	202713	22001555		Fuse
"	203140			Contact Ball Kit
"	NLA		Not Available	FUSE BLOCK WITH FUSE
"	NLA		Not Available	LAMP SOCKET WITH BRACKET
"	NLA		Not Available	TICKET RECEIVER ASSEMBLY
"	204881			Cam Plate Assembly
"	204882		Not Available	SWITCH FOR TICKET CONTROL
013	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping

NI	NLA		Not Available	SPADE CONNECTOR
"	NLA		Not Available	HARNES FOR TICKET CONTROL
"	211737	248562		Terminal
"	NLA		Not Available	OVERLAY FOR CIRCUIT BOARD
"	212452			Board, Circuit
"	NLA		Not Available	SEMS SCREW (No.4-40 X 1/2 INC)
"	212519	488234		Screw 8-32 X 1/4
"	212533			SHIELD FOR HEAT LAMP
"	NLA		Not Available	SCREW, SHIELD TO CONTROL
"	NLA		Not Available	FRONT PLATE F/TICKET CONTRO
"	NLA		Not Available	BRACKET FOR TICKET ASSEMBLY
"	213074			Pin Receptacle For Plug
"	NLA		Not Available	PIN FOR PLUG
"	NLA		Not Available	TICKET DEFLECTOR
"	NLA		Not Available	SCREW (No.6 X 1/4 INCH)
"	NLA		Not Available	SHIELD
"	214218			Lever, Switch
"	214220			Adjustment Thumb Wheel
"	214275			Roller For Cam
"	NLA		Not Available	SCREW
"	NLA		Not Available	SPRING WASHER
"	Y311550		Not Available	SPADE (MINIATURE)
"	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
"	311613	Y311711		Screw, Fuse Block

the laundry company[®]

rows
the laundry company[®]