


Maytag GDG31CM 07 - DOOR SWITCH, TEMP CNTRL, TERMINAL BLOCK

MODEL DG31CA-CM-CT

DOOR SWITCH, TEMPERATURE CONTROL & TERMINAL BLOCK



Maytag [Commercial Maytag GDG31CM Dryer Parts](#) Parts Diagram 07 - DOOR SWITCH, TEMP CNTRL, TERMINAL BLOCK

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052749	62739		Nut, Lock
NI	NLA		Not Available	LOCK WASHER, 3/8 X 1/16
003	210866			Nut, Twin Speed
004	212220	213501		Screw, No.6-20 X 1-1/8 Inch
005	212951			Screw, No.6-32 X 1/4 Inch
NI	NLA		Not Available	CLIP - ACTUATOR TO CABINET
007	Y330077			Door Switch
008	Y330078			Cool-Down Bypass Switch
009	Y330083		Not Available	CONTROL, TEMPERATURE
010	Y330087			Drum Assembly Complete
011	Y330092			Terminal Block
NI	NLA		Not Available	FRONT PANEL-WHITE
"	NLA		Not Available	FRONT PANEL-SHADED AVOCADO
"	NLA		Not Available	FRONT PANEL-ALMOND

015	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
016	NLA		Not Available	FRONT PANEL-SUNSET CORAL
NI	Y330100		Not Available	COIN BOX ASSEMBLY
"	Y330147			Part Not Used
019	NLA		Not Available	VAULT ASSEMBLY
020	NLA		Not Available	SCREW - BRACKET TO VAULT
021	331012	400022-1		Screw
NI	331014	8281196		Screw
023	331026	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
024	NLA		Not Available	SQUARE WASHER FOR DRUM ROD
NI	331058			Grommet-Temp. Control Tubin
"	331061			Knob For Temperature Contro
"	NLA		Not Available	MOUNTING PLATE-DOOR SWITCH
"	NLA		Not Available	DRUM ROD
"	NLA		Not Available	ACTUATOR FOR DOOR SWITCH
030	NLA		Not Available	SCREW-TEMP CONTROL LEVER
NI	NLA		Not Available	BRACKET-TEMPERATURE CONTROL
032	331151			Lever-Temperature Control
NI	NLA		Not Available	NUT FOR CONDUIT
"	331230			Clip
"	NLA		Not Available	TWIN FASTENER WITH SCREWS

the laundry company[®]

the laundry company[®]