


Maytag LA26CD 02 - TOP



4

Maytag [Commercial Maytag LA26CD Washer Parts](#) Parts Diagram 02 - TOP
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	214901		Not Available	LID-WHITE
"	NLA		Not Available	(ALM)
002	211726			Hinge, Ball Lid
003	Y215699	22001678		Bracket, Switch And Fuse
004	Y052740	62739		Nut, Lock
005	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
006	910309			Washer, Mounting Strap
007	207173		Not Available	TOP COVER ASSEMBLY (WHT)
"	NLA		Not Available	(ALM)
008	212716			Bumper, Lid
009	204445			Screw And Fastener Assembly
010	NLA		Not Available	STRAP, MOUNTING
011	910182	25-7809		Screw, No.6-20 1/2 Flthd Torx
012	211500			Washer, Bracket To Top Cover
013	201068			Plunger And Bracket

013	204900		Assembly--W
014	213720		Spring, Lid Switch
015	215704		Lever, Unbalance
016	NLA	Not Available	PLUNGER, LID SWITCH
017	NLA	Not Available	CORD, POWER
018	211881		Grommet, Cord Part Not Used- Gas Models Only
019	207159	489355	Screw, 8 X 1/2
020	205415	279347	Switch-Lid
021	213501		Screw, No.6-20 X 1-1/8 Inch

