


Maytag LDE19CT 06 - MOTOR DRIVE



32

Maytag [Commercial Maytag LDE19CT Dryer Parts](#) Parts Diagram 06 - MOTOR DRIVE

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
002	Y303225			Thermostat, Permanent Press
003	303392			Thermostat, Cycling
004	Y303391	33303391		Thermostat, Cycling
005	Y312853			Cover For Thermostat Openin
006	Y312961	W10116751		Screw
007	410233	9703438		Ring-Retrn
008	312967			Clamp, Blower Housing
009	Y303836			Blower Wheel Assembly And Clamp
010	Y310632	1163839		Screw
011	Y313561			Screw---NA
012	901220			Ground Wire
013	Y303358	W10410999		Motor-Drve
014	NLA		Not Available	WIRE
015	Y015825			Clip, Motor To Motor Support

016	306207		Not Available	(PROD. No.303358-8 & No.303358-9)
"	NLA		Not Available	SWITCH, MOTOR START
"	Y303877		Not Available	SWITCH, MOTOR EXTERNAL START No.303358-2, No.303358-4, 303358-7
"	Y303879			Switch, Motor External Start
017	Y053241			Set Screw, Motor Pulley
018	Y305185	6-3051850		Pulley- MO
019	910343	488234		Screw 8-32 X 1/4
020	Y303945			IDLER SPRING ASSY. W/PLUG
021	Y312959			Poly "V" Belt For Tumbler
022	312958	354987		Ring, Retaining
023	Y312527			Washer, Idler Shaft
024	Y303705	6-3037050		Pulley- ID
025	Y014874			Screw, Idler Arm And Sleeve
026	Y312894	315772		Sleeve, Idler Arm
027	Y303363	6-3033630		Idler Arm
028	Y313582	W10116756		Spacer
029	NLA		Not Available	SUPPORT, MOTOR
030	Y303442			EXHAUST DUCT ASSEMBLY
031	Y312893			Housing, Blower
032	Y313770			COVER FOR BLOWER HOUSING
033	Y312901			Seal, Housing Cover
034	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
035	Y052740	62739		Nut, Lock
036	Y305086			Adjustable Leg And Nut
037	Y314137			Foot, Rubber
038	Y313262	W10116752		Retainer-
039	410490			Spring, Retainer Wire Harness

