


Maytag LDE19CT 10 - CONTROL CENTER COMPONENTS



Maytag [Commercial Maytag LDE19CT Dryer Parts](#) Parts Diagram 10 - CONTROL CENTER COMPONENTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW
002	204882		Not Available	SWITCH FOR TICKET CONTROL
003	NLA		Not Available	SEMS SCREW (No.4-40 X 1/2 INC)
004	204881			Cam Plate Assembly
005	214218			Lever, Switch
006	212452			Board, Circuit
007	214275			Roller For Cam
008	214220			Adjustment Thumb Wheel
009	NLA		Not Available	SPRING WASHER
010	202479	A3167501		Lamp Oven, Int.
011	NLA		Not Available	LAMP SOCKET WITH BRACKET
012	NLA		Not Available	SCREW, SHIELD TO CONTROL
013	NLA		Not Available	FRONT PLATE F/TICKET CONTRO

014	212533			SHIELD FOR HEAT LAMP
015	Y201110		Not Available	CONNECTOR, WIRE (INDIC. LIGHT)
016	212519	488234		Screw 8-32 X 1/4
017	NLA		Not Available	TICKET DEFLECTOR
018	203140			Contact Ball Kit
019	NLA		Not Available	OVERLAY FOR CIRCUIT BOARD
020	Y311550		Not Available	SPADE (MINIATURE)
021	NLA		Not Available	JUMPER WIRE (BLACK)
022	NLA		Not Available	SPADE CONNECTOR
023	211737	248562		Terminal
024	NLA		Not Available	HARNESS FOR TICKET CONTROL
025	213074			Pin Receptacle For Plug
"	NLA		Not Available	PIN FOR PLUG
026	202713	22001555		Fuse
027	NLA		Not Available	SCREW (No.6 X 1/4 INCH)
028	311613	Y311711		Screw, Fuse Block
029	311612		Not Available	COVER, CIRCUIT BOARD TERMINALS
030	NLA		Not Available	BRACKET FOR TICKET ASSEMBLY
031	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
032	NLA		Not Available	SHIELD
033	202477	22003292		Control As
034	NLA		Not Available	FUSE BLOCK WITH FUSE
035	NLA		Not Available	TICKET RECEIVER ASSEMBLY
036	202509			Ticket Control Assembly

the laundry company[®]

laundries
the laundry company[®]