


Maytag LDG18CT 01 - FRONT VIEW



Maytag Commercial Maytag LDG18CT Dryer Parts Parts Diagram 01 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	SCREW, No.4-40 X 1/4
002	204051	22204051		Knob
003	204439			Screw And Fstner Assembly
004	204445			Screw And Fastener Assembly
005	210385			Lock Nut For Adjustable Leg
006	210684			Foot, Adjustable Leg
007	212276	W10116760		Screw
008	212519	488234		Screw 8-32 X 1/4
009	212949	22001866		Screw, Relay
010	213007			Xfor Cabinet See Cabinet, Back
011	NLA		Not Available	GASKET UNDER CONTROL CENTER
012	213099			Lens For Control Panel
013	213949			Screw, No.8-18 X 5/16 Inch
014	NLA		Not Available	HINGE ASSEMBLY----N
015	NLA		Not Available	CONTROL COVER-WHITE

016	NLA		Not Available	CONTROL COVER-HARVEST WHEAT
017	NLA		Not Available	LATCH
018	NLA		Not Available	ACCESS DOOR (WHITE)
019	NLA		Not Available	ACCESS DOOR-ALMOND
020	NLA		Not Available	ACCESS DOOR-HARVEST WHEAT
021	NLA		Not Available	PILOT LIGHT
022	Y302699	22003428		Leg, Adjustable
023	Y303318			Switch Assembly With Hex Nu
024	NLA		Not Available	CABINET-WHITE
025	NLA		Not Available	CABINET-ALMOND
026	NLA		Not Available	CABINET-HARVEST WHEAT
027	Y303370			Door Switch
028	Y303390		Not Available	LINT SCREEN
029	NLA		Not Available	DOOR COMPLETE-WHITE
030	NLA		Not Available	DOOR COMPLETE-HARVEST WHEAT
031	NLA		Not Available	TOP COVER-WHITE
032	NLA		Not Available	TOP COVER-ALMOND
033	NLA		Not Available	TOP COVER-HARVEST WHEAT
034	Y303420		Not Available	SELECTOR SWITCH
035	Y303441		Not Available	DOOR SWITCH
036	Y303703			Pilot Light
037	Y303786		Not Available	LINT SCREEN WITH RETAINER
038	NLA		Not Available	FRONT PANEL-WHITE
039	NLA		Not Available	FRONT PANEL-HARVEST WHEAT
040	NLA		Not Available	CONTROL CENTER-WHITE
041	NLA		Not Available	CONTROL CENTER-ALMOND
042	NLA		Not Available	CONTROL CENTER-HARVEST WHEA
043	NLA		Not Available	CONTROL CENTER-WHITE
044	NLA		Not Available	CONTROL CENTER-HARVEST WHEA
045	NLA		Not Available	HINGE - LOWER
046	NLA		Not Available	HINGE - UPPER
047	Y304648	33001106		Back, Tumbler
048	NLA		Not Available	KNOB AND SCREW
049	310560	74004005		Screw, 6-32 X 5/16"
050	NLA		Not Available	WASHER
051	NLA		Not Available	WIRE CLIP
052	NLA		Not Available	STRIKE PLATE
053	NLA		Not Available	BACK FOR CONTROL PANEL
054	NLA		Not Available	BUSHING FOR ACCESS STUD
055	NLA		Not Available	SCREW---NA
056	312369			Sleeve, Access Panel Stud Part Not Used
057	NLA		Not Available	MAGNETIC LATCH RETAINER
058	NLA		Not Available	DOOR PANEL-WHITE
059	NLA		Not Available	DOOR PANEL-HAVEST WHEAT
060	Y312891		Not Available	DOOR LINER - INNER HALF

061	Y312907		Tumbler Baffle
062	NLA	Not Available	CONTROL PANEL
063	313122		Screw - Baffle To Tumbler
064	Y313340		LABEL, LINT SCREEN INSTRUCTION
065	Y313541	33313541	Seal- Tumbler
066	Y313927		INSTRUCTION LABEL
067	314077		Door Seal
068	NLA	Not Available	GAS IGNITION LABEL

