


Maytag LDG19CS 02 - CONTROL PANEL



8

Maytag [Commercial Maytag LDG19CS Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	215003			Fastener, Panel And Bracket
002	305213			Console-White
"	NLA		Not Available	(ALM)
003	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y314322	211251		Screw, Transformer
004	Y305396		Not Available	LAMP, INDICATOR
005	212276	W10116760		Screw
006	Y303204			Start Switch With Nuts
007	NLA		Not Available	LABEL KIT, SPANISH
008	312751			Lockwasher, Start Switch
009	Y312706	422617		Nut
010	NLA		Not Available	BACK UP PLATE (WHT)
012	Y312702			Knurled Nut, Start Switch
013	213099			Lens For Control Panel
014	211252			Screw, Ground Wire
015	NLA		Not Available	CONTROL PANEL

016	NLA	Not Available	(ALM)
"	Y305191	Not Available	TOP COVER-WHITE
017	205663		Knob For Selector Switch
018	Y313588	488234	Screw 8-32 X 1/4
019	Y303420	Not Available	SELECTOR SWITCH
020	NLA	Not Available	MAIN WIRE HARNESS
314	212277		Screw, No.8 X 1/2 Inch

