


# Maytag LDG21CS 01 - FRONT VIEW



Maytag Commercial Maytag LDG21CS Dryer Parts Parts Diagram 01 - FRONT VIEW  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y052740</a>	<a href="#">62739</a>		Nut, Lock
002	<a href="#">204439</a>			Screw And Fstner Assembly
003	<a href="#">204445</a>			Screw And Fastener Assembly
004	<a href="#">210385</a>			Lock Nut For Adjustable Leg
005	<a href="#">210684</a>			Foot, Adjustable Leg
006	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
007	<a href="#">211294</a>	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
008	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
009	NLA		Not Available	ACCESS DOOR (WHITE)
010	Y302699	<a href="#">22003428</a>		Leg, Adjustable
011	NLA		Not Available	TOP COVER-WHITE
012	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
013	NLA		Not Available	SPACER ASSM-WHITE
014	NLA		Not Available	CABINET-WHITE

015	304045		Not Available	CABINET-WHITE
"	NLA		Not Available	CABINET-ALMOND
016	NLA		Not Available	NAME PLATE ON CONTROL PANEL
017	NLA		Not Available	FRONT PANEL-WHITE
018	NLA		Not Available	FRONT PANEL-WHITE
019	<a href="#">304965</a>			Door Complete-White
"	NLA		Not Available	DOOR COMPLETE, ALMOND
020	Y305087	<a href="#">22003544</a>		Adjustable Leg W/Foot And Nut
021	NLA		Not Available	INNER DOOR WITH KNOB & SCRE
022	NLA		Not Available	KNOB AND SCREW
023	Y310632	<a href="#">1163839</a>		Screw
024	310933	<a href="#">33002194</a>		Nut, Speed
025	NLA		Not Available	COVER PLATE FOR TOP COVER
026	<a href="#">Y313559</a>			Screw
027	<a href="#">33001303</a>			Grommet, Plate Hole
028	NLA		Not Available	SCREW
029	910768	<a href="#">M0280301</a>		Tie Electr

