



[Maytag Commercial Maytag LDG21CS Dryer Parts](#) Parts Diagram 03 - CONTROL CENTER SHROUD
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y014872			Screw, Coin Meter Stop -
002	Y052740	62739		Nut, Lock
003	NLA		Not Available	MTG. STRAP----NA
004	204051	22204051		Knob
005	NLA		Not Available	COIN BOX-WHITE----NA
006	NLA		Not Available	MAYTAG COIN SLIDE
007	NLA		Not Available	SCREW, HEX HD No.8 X 1/2 INCH
008	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
009	212276	W10116760		Screw
010	212519	488234		Screw 8-32 X 1/4
011	NLA		Not Available	SPRING WASHER FOR LOCK
012	213648	98165		Screw
013	214650			Screw For 2-4051 Knob
014	Y303204			Start Switch With Nuts

015	Y303420		Not Available	SELECTOR SWITCH
016	303963		Not Available	LIGHT, INDICATOR
017	NLA		Not Available	CONTROL SHROUD-WHITE
018	NLA		Not Available	VAULT ASSEMBLY
019	Y303981			Ground Wire For Latch
020	NLA		Not Available	OUTER CASE-WHITE
021	NLA		Not Available	COIN METER STOP WITH SCREWS
022	Y310632	1163839		Screw
023	Y312702			Knurled Nut, Start Switch
024	Y312706	422617		Nut
025	312751			Lockwasher, Start Switch
026	NLA		Not Available	BRACKET FOR SWITCH & RELAY
027	NLA		Not Available	INSULATOR
028	Y313424			Screw, Vault Panel
029	Y313427	206637		Lock Kit
030	313428		Not Available	PLATE FOR LATCH
031	NLA		Not Available	CONTROL PANEL FOR VAULT
032	Y313559			Screw
033	Y313671	33001303		Grommet, Plate Hole
034	910768	M0280301		Tie Electr

