


Maytag LDG24CS 02 - CS CONTROL PANEL/COIN BOX



+Contact your commercial laundry distributor for locks and keys.

Maytag [Commercial Maytag LDG24CS Dryer Parts](#) Parts Diagram 02 - CS CONTROL PANEL/COIN BOX
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y052634	701719		Nut, Hex
002	Y052721			Nut, Terminal Block Plate
003	Y052740	62739		Nut, Lock
004	203188		Not Available	TIMER ACCESS DOOR (WHT)
005	203188L		Not Available	ACCESS DOOR-ALMOND
006	203188M		Not Available	ACCESS DOOR-HARVEST WHEAT
007	NLA		Not Available	MTG. STRAP---NA
008	205423	208883		Coin Box K
009	205423L	208883		Coin Box K
010	205423M	208883		Coin Box K
011	206956	22001405		Case, Coin Slide
012	206956L	22001405		Case, Coin Slide
013	206956M	22001405		Case, Coin Slide
014	211065			Spring, Index Wheel
015	211168	W10139210		Screw, 8-18 X 5/16

016	211790		Lock Ring For Timer Shaft
017	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
018	212328	W10139762	Hex Nut, 3/4-27
019	212707	3196385	Screw
020	213750	W10133266	Cam-Lock
021	214648		Decal, Coinage
022	214660		Gasket, Control Center
023	215559		Bolt, Coin Slide Locking
024	305796		Timer
025	305797		Torsion Timer Assembly Complete
026	305798	Not Available	BYPASS SWITCH FOR MOTOR
027	Y305799		Bypass Switch For Heater
028	305800		Wire Harness For Timer
029	305813		Part Not Available Part Not Used
030	305870		Timer Motor
031	306104		Actuator Switch Kit
032	Y312270		Clip, Spring Retainer
033	314330	Not Available	DRIVER FOR INDEX WHEEL (NOT INCLUDED W/KIT)
034	314331		Spring, Torsion Return
035	314332		Spring, Actuator
036	314333		Timer Mounting Bracket
037	314334		Bracket For Coin Slide
038	314335		Peg, Tine Adjustment
039	314337	33002968	Slider
040	314339		Switch And Slider Bracket
041	NLA	Not Available	HELICAL SPRING ----N
042	NLA	Not Available	INSTRUCTION LABEL
043	NLA	Not Available	SCREW
044	NLA	Not Available	STOP FOR TIMER MECHANISM
045	314546		Wheel, Index
046	314547	Y308109	Slide And Adj. Return Bracket
047	314548	33002967	Actuator, Switch
048	910309		Washer, Mounting Strap
049	910387		Lockwasher, Vault Assembly
050	910708	488234	Screw 8-32 X 1/4

the laundry company[®]