


Maytag LDG26CS 04 - FRONT VIEW



Maytag Commercial Maytag LDG26CS Dryer Parts Parts Diagram 04 - FRONT VIEW
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	ACCESS DOOR W/DECAL (WHT)
002	Y305086			Adjustable Leg And Nut
003	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
004	NLA		Not Available	CABINET (WHT)
005	205423	208883		Coin Box K
"	205423L	208883		Coin Box K
"	205423M	208883		Coin Box K
006	NLA		Not Available	CONTROL COVER (WHT)
007	NLA		Not Available	(ALM)
"	Y307111		Not Available	DOOR ASSY. COMPLETE (WHT)
008	307998L			Front Panel---NA
"	NLA		Not Available	FRONT PANEL (WHT)
009	214660			Gasket, Control Center
010	314946			Handle White

"	314972		Handle Door ALM
"	NLA		Not Available (H. WHEAT)
011	Y052740	62739	Nut, Lock
012	213750	W10133266	Cam-Lock
013	NLA		Not Available MTG. STRAP---NA
014	206956	22001405	Case, Coin Slide
"	206956L	22001405	Case, Coin Slide
"	206956M	22001405	Case, Coin Slide
015	314966		Panel, Outer
"	NLA		Not Available (ALM)
016	Y314137		Foot, Rubber
017	213007		Xfor Cabinet See Cabinet, Back
018	Y310632	1163839	Screw
019	212276	W10116760	Screw
020	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
021	204439		Screw And Fstner Assembly
022	204445		Screw And Fastener Assembly
023	203188		Not Available TIMER ACCESS DOOR (WHT)
"	203188L		Not Available ACCESS DOOR-ALMOND
"	203188M		Not Available ACCESS DOOR-HARVEST WHEAT
024	307105		Not Available COVER, TOP ASSY. (WHT)
"	NLA		Not Available (ALM)
025	910309		Washer, Mounting Strap

the laundry company[®]

the laundry company[®]