


Maytag LDG27CA 02 - REAR VIEW

SECTION: REAR VIEW
MODEL: DE-DG27CA



Maytag [Commercial Maytag LDG27CA Dryer Parts](#) Parts Diagram 02 - REAR VIEW
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	302521		Not Available	CORD, POWER PART NOT USED-GAS MODELS ONLY
002	211881			Grommet, Cord Part Not Used-Gas Models Only
003	Y313561			Screw---NA
"	Y312905		Not Available	COVER, TERMINAL
004	214519			LABEL, ELECTRICAL INSTR. PART NOT USED-GAS MODELS ONLY
005	Y312184			Strap, Grounding
006	400008			Block, Terminal
007	Y312904			Bracket, Terminal Block
008	Y311270			Washer, Terminal Block
009	311484	112432		Nut
010	307104			Top Cover Assembly
011	NLA		Not Available	COVER PLATE
"	Y313559			Screw
012	NLA		Not Available	SCREW & WASHER ASSY.

013	213007		Xfor Cabinet See Cabinet, Back
"	NLA	Not Available	CABINET (WHT)
"	Y310632	1163839	Screw
014	310933	33002194	Nut, Speed
015	NLA	Not Available	SUPPORT ASSY
"	Y310632	1163839	Screw
016	213007		Xfor Cabinet See Cabinet, Back
"	Y313561		Screw----NA
"	NLA	Not Available	CABINET, LOWER (WHITE)
"	Y310632	1163839	Screw
017	210385		Lock Nut For Adjustable Leg
018	Y302699	22003428	Leg, Adjustable
019	210684		Foot, Adjustable Leg
020	211294	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
"	Y313561		Screw----NA
"	Y312951	Not Available	ACCESS COVER, BACK
021	301548		Clamp, Ground Wire
"	313122		Screw - Baffle To Tumbler
022	311155		Ground Wire And Clamp

