


Maytag LDG33CM 04 - DOOR SWITCH, TEMP CONTROL & TERMINAL BLK



Maytag Commercial Maytag LDG33CM Dryer Parts Parts Diagram 04 - DOOR SWITCH, TEMP CONTROL & TERMINAL BLK

Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|-------------------------|---------------|---------------------------------|
| 001 | 210866 | | | Nut, Twin Speed |
| 002 | NLA | | Not Available | CAGE NUT |
| 003 | 212951 | | | Screw, No.6-32 X 1/4 Inch |
| 004 | 213966 | 3400014 | | Screw |
| 005 | 214884 | 213501 | | Screw, No.6-20 X 1-1/8 Inch |
| 006 | Y330073 | | | Valve, Shut-Off |
| 007 | Y330078 | | | Cool-Down Bypass Switch |
| 008 | Y330083 | | Not Available | CONTROL, TEMPERATURE |
| 009 | Y330092 | | | Terminal Block |
| 010 | NLA | | Not Available | HINGE, DOOR |
| 011 | Y330226 | | | Wire, Ignition Control Assembly |
| 012 | Y330228 | | | Harness For Gas Valve |
| 013 | Y330230 | | | Ignition Control Assembly |
| 014 | Y330231 | | | Transformer |

| | | | | |
|-----|-------------------------|--------------------------|---------------|---|
| 015 | Y330232 | | Not Available | DOOR SWITCH |
| 016 | Y330241 | | Not Available | PANEL, FRONT (WHITE) |
| 017 | 330241L | | Not Available | (ALMOND) |
| 018 | NLA | | Not Available | (H. WHEAT) |
| 019 | Y330242 | | Not Available | VAULT ASSEMBLY |
| 020 | Y330253 | | | Fuse |
| 021 | Y330254 | | | Fuse Block |
| 022 | Y330294 | | | COIN BOX ASSEMBLY |
| 023 | NLA | | Not Available | SCREW, BRACKET (VAULT) |
| 024 | 331014 | 8281196 | | Screw |
| 025 | NLA | | Not Available | CABLE CLAMP |
| 026 | 331026 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 027 | 331032 | 61002031 | | Screw, Handle |
| 028 | 331036 | | | Washer-Front Panel Screws |
| 029 | 331058 | | | Grommet-Temp. Control Tubin |
| 030 | 331061 | | | Knob For Temperature Contro |
| 031 | NLA | | Not Available | GAS SUPPLY LINE-28 1/2 INCH |
| 032 | 331084 | | Not Available | SUPPORT ROD FOR UPPER DOOR |
| 033 | NLA | | Not Available | BRACKET-TEMPERATURE CONTROL |
| 034 | 331151 | | | Lever-Temperature Control |
| 035 | 331167 | | | Gasket For Door-Outer |
| 036 | NLA | | Not Available | NUT, CONDUIT |
| 037 | NLA | | Not Available | GROMMET, TEMP. CONTROL TUBIN |
| 038 | 331193 | | Not Available | COVER FOR DOOR SWITCH BOX |
| 039 | 331197 | | Not Available | SHIELD FOR DOOR SWITCH |
| 040 | 331198 | | | Actuator For Door Switch |
| 041 | 331199 | | Not Available | GASKET FOR DOOR GLASS |
| 042 | 331201 | | | Door Switch Box |
| 043 | 331204 | 61003351 | | Screw, Handle To Frame |
| 044 | NLA | | Not Available | SCREW |
| 045 | NLA | | Not Available | TWIN FASTENER |
| 046 | NLA | | Not Available | WASHER, COIN BOX LOCK |
| 047 | NLA | | Not Available | TWIN FASTENER W/SCREWS |

