


# Maytag LDGS30PC1 01 - CONTROL DOOR ASSEMBLY



Maytag [Commercial Maytag LDGS30PC1 Dryer Parts](#) Parts Diagram 01 - CONTROL DOOR ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A880112	<a href="#">W10147948</a>		430 Contro
002	A180226		Not Available	CONTROL DOOR GRAPHIC TRIM
003	A180225	<a href="#">180225</a>		430 Control L
004	A150201	<a href="#">150201</a>		10-32 X 1
006	A150301	<a href="#">150301</a>		8-18 X 7
007	A160040	<a href="#">160040</a>		Dp Control
008	A160140	<a href="#">160140</a>		Key Only F
"	A404500	<a href="#">WB22X55</a>		Switch
"	A404502	<a href="#">404502</a>		White 0.6