


Maytag LDGS30PC1 08 - MAIN DOOR ASSEMBLY



Maytag [Commercial Maytag LDGS30PC1 Dryer Parts](#) Parts Diagram 08 - MAIN DOOR ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A170730	170730		10.3 Oz CI
"	A800145		Not Available	ALMOND DOOR LESS ACCESSORIES
"	A800146	W10146975		White Mag
"	A800147	W10146976		Almond Mag
"	A800148	W10146977		White Mag
002	A103050		Not Available	HINGE, DOOR
003	A150410	MC80MD		Elmntsurf
004	A152014	152014		1 4-20 Ser
005	A102350	W10149210		68 1 2 Do
006	A102210	102210		20 7 16 D
007	A150002	150002		6-32 X 1
008	A102105	102105		Magnet Hol
009	A152013	152013		6-32 Hex N

010	A306802	306802	Wire Harness
011	A102102	102102	Door Magnet
012	A150410	MC80MD	Elmntsurf
013	A404500	WB22X55	Switch
"	A404502	404502	White 0.6
"	A800131	W10146966	Cast Magnet

