

# Maytag MAF18MC4VS 02 - DOOR & RELATED PARTS (MAF18MC4Vx)



Maytag [Commercial Maytag MAF18MC4VS Washer Parts](#) Parts Diagram 02 - DOOR & RELATED PARTS (MAF18MC4Vx)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">24001638</a>			Door Assembly
"	NLA		Not Available	DOOR
002	<a href="#">24001075</a>			Gasket, Door
003	24001098		Not Available	GLASS, DOOR
004	<a href="#">24001333</a>			Hinge, Door
005	<a href="#">24001334</a>			Mount, Door
006	W10124350		Not Available	PART NUMBER NOT AVAILABLE
007	24001341	<a href="#">3400814</a>		Screw
008	<a href="#">24001305</a>			Nut, Fiberlock
009	<a href="#">24001467</a>			Screw, S.s.
010	<a href="#">24001103</a>			Rod, Push Button
011	<a href="#">24001336</a>			Handle, Door
012	<a href="#">24001721</a>			Pin, Spring
013	<a href="#">24001338</a>			Spring, Door Lock
014	24001310	<a href="#">Y015627</a>		Screw- Hex

015	24001340		Not Available	SPACER, DOOR HANDLE
016	<a href="#">24001343</a>			Arm, Latch
017	24001342	<a href="#">74005230</a>		Nut, Lock
018	24001133		Not Available	KIT, PNL, FRT COIN (STLS.)
"	24001728		Not Available	OUTER PANEL KIT (COIN ALM)
"	NLA		Not Available	KIT, OTR. PNL COIN (SS COR)
019	<a href="#">24001474</a>	<a href="#">3400086</a>		Screw, 10-32 X 3/8
020	24001722		Not Available	TRIM, OUTER FRONT PANEL
021	24001827	<a href="#">24001721</a>		Pin, Spring
022	<a href="#">24001466</a>			Shim, Hinge
023	24001462		Not Available	DECAL, PUSH BUTTON RED
024	24001407		Not Available	DECAL, RED DOT

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>