


# Maytag MAF25MC3 05 - DOOR & RELATED ASSEMBLY



Maytag [Commercial Maytag MAF25MC3 Washer Parts](#) Parts Diagram 05 - DOOR & RELATED ASSEMBLY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	24001407		Not Available	DECAL, RED DOT
002	<a href="#">24001103</a>			Rod, Push Button
003	<a href="#">24001721</a>			Pin, Spring
004	<a href="#">24001338</a>			Spring, Door Lock
005	<a href="#">24001336</a>			Handle, Door
006	<a href="#">24001339</a>			Washer, Nylon
007	24001341	<a href="#">3400814</a>		Screw
008	24001462		Not Available	DECAL, PUSH BUTTON RED
009	24001636	<a href="#">24001638</a>		Door Assembly
"	<a href="#">24001638</a>			Door Assembly
"	NLA		Not Available	DOOR ONLY (OPL)
010	24001340		Not Available	SPACER, DOOR HANDLE
011	24001342	<a href="#">74005230</a>		Nut, Lock
012	<a href="#">24001075</a>			Gasket, Door
013	<a href="#">24001343</a>			Arm, Latch
014	24001465		Not Available	DECAL, ROTATION SPIN (CCW)

015	24001098		Not Available	GLASS, DOOR
016	W10124350		Not Available	PART NUMBER NOT AVAILABLE
017	<a href="#">24001466</a>			Shim, Hinge
018	<a href="#">24001333</a>			Hinge, Door
019	<a href="#">24001305</a>			Nut, Fiberlock
020	<a href="#">24001334</a>			Mount, Door
021	<a href="#">24001467</a>			Screw, S.s.
022	24001417	<a href="#">7103P070-60</a>		Nut, Top Pilot
023	<a href="#">24001415</a>			Washer, S.s.
024	24001470		Not Available	MAGNET
025	<a href="#">24001414</a>	<a href="#">4450038</a>		Screw
026	<a href="#">24001472</a>			Switch, Magnet Position
027	<a href="#">24001185</a>			Gasket Kit
028	24001135		Not Available	(INCLUDES TRIM & SCREWS)
"	24001136		Not Available	PANEL KIT, FRONT COIN (ALM) (INCLUDES TRIM & SCREWS)
"	24001137		Not Available	PANEL KIT, FRONT COIN (STNLSS) (INCLUDES TRIM & SCREWS)
"	NLA		Not Available	PANEL KIT, FRONT COIN (WHT)
029	<a href="#">24001474</a>	<a href="#">3400086</a>		Screw, 10-32 X 3/8
030	24001475		Not Available	RIVET, POP S.S. (1/8 X 1/4)

