


Maytag MAF25PC2 05 - DOOR LOCK



Maytag [Commercial Maytag MAF25PC2 Washer Parts](#) Parts Diagram 05 - DOOR LOCK
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	24001394		Not Available	DOOR LOCK COMPLETE (MN 110V)
"	24001640			Door Lock Complete
"	24001641			Door Lock Complete
"	24001642			Screw, S.s.
"	NLA		Not Available	KIT ASSY., DOOR
002	24001483		Not Available	CATCH, DOOR LOCK
003	24001323			Screw
004	24001484		Not Available	COVER, DOOR LOCK PLATE
005	24001295			Lockwasher, S.s.
006	24001342	74005230		Nut, Lock
007	24001485			Washer, Shoulder
008	24001101			Solenoid, Door Rel
009	24001358			Washer, Flat
010	24001250			Button, Push
"	24001486		Not Available	BUTTON, PUSH (STOP)
011	24001481	Y707702		Locknut

012	24001480		Washer, Teflon
013	24001487	Not Available	COVER, DOOR LOCK ASSY.
014	24001476		Nut, Fiberlock
015	24001229		Switch, Door Lock
016	24001477	Not Available	SPACER, NYLON (No.6)
017	24001479		Screw, S.s.
018	24001643		Screw, S.s.
019	24001301	67006964	Screw, Glide
020	NLA	Not Available	PLATE, DOOR LOCK
021	24001102		Solenoid, Door Lck
022	24001305		Nut, Fiberlock
023	24001255		Switch, Door Handle
"	24001257	24001255	Switch, Door Handle
024	24001425		Nut, Fiberlock, Pltd
025	24001230		Lever, Door Lock
026	24001293		Spring, Torsion
027	24001559		Shim, Door Lock
028	24001488	Not Available	SHIELD, SPLASH (DOOR LOCK)
029	24001645	Not Available	WIRING, HARNESS DOOR LOCK (MN)

