


Maytag MAH14PDBGW 11 - DOOR LATCH ASSY



Maytag [Commercial Maytag MAH14PDBGW Washer Parts](#) Parts Diagram 11 - DOOR LATCH ASSY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22003716			Rotating Gear, Latch
002	22003717			Spring, Latch
003	22001352			Screw, Check Switch
004	22002165			Washer, Door Lock Switch
005	22002162			Switch, Door Lock Spin Enable
006	22002158			Spring, Gear Return
007	22003722			Switch Holder Assembly, Latch
008	22003719			Screw, Latch
009	22003720			Nut, Latch
010	22002957			Cover, Latch Assembly
011	22002435	241877		Screw
012	22003055			Ramp, Door Hoop
013	22002164			Cable, Door
014	22003715			Sliding Gear, Latch
015	22003721			Spring, Axle / Latch
016	22003718			Axle, Latch

