


Maytag MAH14PDSAW 05 - DOOR SHROUD & DOOR LATCH ASSEMBLY



Maytag Commercial Maytag MAH14PDSAW Washer Parts Parts Diagram 05 - DOOR SHROUD & DOOR LATCH ASSEMBLY

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	22003716			Rotating Gear, Latch
002	22003717			Spring, Latch
003	22001352			Screw, Check Switch
004	22002165			Washer, Door Lock Switch
005	22002162			Switch, Door Lock Spin Enable
006	22002158			Spring, Gear Return
007	22003722			Switch Holder Assembly, Latch
008	22003719			Screw, Latch
009	22003720			Nut, Latch
010	22002957			Cover, Latch Assembly
011	22002435	241877		Screw
012	22003055			Ramp, Door Hoop
013	22002164			Cable, Door
014	22003715			Sliding Gear, Latch
015	22003721			Spring, Axle / Latch

016	22003718	Axle, Latch
017	22002119	Motor, Wax
018	22001996	3370225 Screw
019	22002014	Clip, Harness To Support
020	22002095	12001994 Cover
021	22002015	Support, Door Lock
"	22003637	BRACE ASSEMBLY, TOP CROSS CONTAINS ITEMS 12 & 13
022	22002234	Shroud And Dispenser Hose
023	22001995	Screw Note: Screw, Tumbler Front And Shroud
024	Y310376	Clip, Door Switch Harness
025	22002046	Switch, Secondary Door

the laundry company[®]

the laundry company[®]

the laundry company[®]