


Maytag MAH20PDCXW 06 - DOOR & FRONT PANEL (MAH20PDCXx)



Maytag [Commercial Maytag MAH20PDCXW Washer Parts](#) Parts Diagram 06 - DOOR & FRONT PANEL (MAH20PDCXx)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
001	22002002	22003222		Hoop, Lock
002	22002003			Spring, Latch
003	22002168			Support, Lock Hoop
004	22002539	22003083		Liner, Door Assembly W/Vent
"	22002615	22003085		Liner, Door Assembly W/Vent
"	22003076	22003083		Liner, Door Assembly W/Vent
"	22003078			Door, Inner
"	22003800			Inner Door/Vented
005	22002038			Clip, Door
006	22002039			Clip, Door
007	22002104			Frame, Wire
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE
008	22002356			Spring, Plate
"	W10124350		Not Available	NOT REQUIRED PART OR SEE NOTE

009	22002094		Frame, Wire
"	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE
010	22002007		Screw, Wire Frame
"	W10124350	Not Available	NOT REQUIRED PART OR SEE NOTE
011	22001979		Door, Outer
"	22002660	Not Available	DOOR, OUTER (BSQ-W/DAMPER)
012	22002000	22002798	Hinge, Door
013	22002062	98006631	Screw
014	22002063		Screw No.8-18AB Wafer Head
"	33002351		Screw
015	22002049		Clip Note: Clip, Front Panel
"	22002663	Not Available	PANEL, FRONT (BISQ)
"	22002836		Panel, Front
016	22002243		Screw, Front Panel And Hinge
"	22002244		Clip, Grounding
017	22002990	22003850	Vent Tube Assembly
018	22003075		Grommet, Vent Tube
019	22003083		Liner, Door Assembly W/Vent
"	22003085		Liner, Door Assembly W/Vent

