


# Maytag MAH21PDDXW 02 - CONTROL CENTER



\* CONTACT YOUR COMMERCIAL LAUNDRY DISTRIBUTOR

Maytag [Commercial Maytag MAH21PDDXW Washer Parts](#) Parts Diagram 02 - CONTROL CENTER

[Click on the part number to view part](#)

| Item | Original Part Number     | Replaced By               | Status        | Part Description                              |
|------|--------------------------|---------------------------|---------------|---|
| 001  | <a href="#">22002480</a> |                           |               | Vault, Coin PD Coin Drop<br>Supplied By Dist. |
| "    | 33002428                 | <a href="#">22002480</a>  |               | Vault, Coin PD Coin Drop<br>Supplied By Dist. |
| 002  | 22001810                 |                           | Not Available | STRAP, MOUNTING                               |
| 003  | 22002925                 | <a href="#">3370225</a>   |               | Screw   |
| 004  | <a href="#">910309</a>   |                           |               | Washer, Mounting Strap                        |
| 005  | <a href="#">22002072</a> |                           |               | Gasket, Control Center                        |
| "    | <a href="#">22002618</a> |                           |               | Gasket, Control Center                        |
| 006  | <a href="#">Y052740</a>  | <a href="#">62739</a>     |               | Nut, Lock                                     |
| 007  | 22001903                 | <a href="#">8576635</a>   |               | Bolt  |
| 008  | <a href="#">910181</a>   |                           |               | Lockwasher, Terminal Block                    |
| 009  | <a href="#">22003677</a> |                           |               | Nut, Locking Cam                              |
| 010  | <a href="#">33001250</a> |                           |               | Switch, Vault And Service<br>Door             |
| 011  | 22003678                 | <a href="#">22004112</a>  |               | Coin Drop Greenwald Us.25                     |
| "    | 22004113                 | <a href="#">W10133245</a> |               | Dual Coin Drop Assembly                       |

|     |                          |                               |
|-----|--------------------------|-------------------------------|
| "   | <a href="#">22004114</a> | Coin Drop Greenwald .25       |
| "   | <a href="#">33002644</a> | Dual Faceplate Assembly       |
| "   | <a href="#">33002646</a> | Coin Drop-Canada              |
| "   | <a href="#">33002647</a> | Single Faceplate Assembly     |
| 012 | <a href="#">216200</a>   | Face Plate Return Button      |
| 013 | <a href="#">22003679</a> | Timer Access Door Assembly    |
| "   | <a href="#">22003692</a> | Timer Access Door Assembly    |
| 014 | <a href="#">22001965</a> | Optic Switch Assembly         |
| 015 | <a href="#">314665</a>   | Screw, Switch Assembly        |
| 016 | <a href="#">22001069</a> | Screw, Vault To Control Cover |
| 017 | <a href="#">22001404</a> | Bracket, Service Switch       |
| 018 | <a href="#">22001069</a> | Screw, Vault To Control Cover |
| 019 | <a href="#">22001966</a> | Harness, Sensor Switch        |

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>