


# Maytag MAT25DAAAL 01 - CONTROL PANEL



Maytag [Commercial Maytag MAT25DAAAL Washer Parts](#) Parts Diagram 01 - CONTROL PANEL  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">206780</a>			Control Cover Assembly
"	206780L	<a href="#">206780</a>		Control Cover Assembly
"	NLA		Not Available	(HWT)
002	NLA		Not Available	TRANSFORMER
003	212276	<a href="#">W10116760</a>		Screw
004	<a href="#">211294</a>	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
"	<a href="#">Y313559</a>			Screw
005	<a href="#">203970</a>			Switch, Water Level
006	<a href="#">211294</a>	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
007	410296	<a href="#">596669</a>		Clamp, Manifold
008	212942	<a href="#">22001619</a>		Tube, Water Level Switch
009	<a href="#">215003</a>			Fastener, Panel And Bracket
010	NLA		Not Available	CIRCUIT BOARD ASSEMBLY
011	<a href="#">206881</a>			Indicator, Light
012	NLA		Not Available	ENCLOSURE, CIRCUIT

012	NLA	Not Available	BOARD
013	NLA	Not Available	BRACKET (WHT)
014	<a href="#">312956</a>		Screw-Igniter And Clip Mount
015	NLA	Not Available	WINDOW, DATA
016	208061	Not Available	(GREEN & AMBER LENS)
"	NLA	Not Available	PANEL, CONTROL
017	<a href="#">206894</a>		Knob, Selector
018	<a href="#">Y313588</a>	<a href="#">488234</a>	Screw 8-32 X 1/4
019	<a href="#">215506</a>		Screw, Control Panel Overlay
020	Y314322	<a href="#">211251</a>	Screw, Transformer
021	<a href="#">205810</a>		Wire, Ground
022	216042	<a href="#">22001627</a>	Screw
023	<a href="#">205353</a>		Switch, DiAl-A-Fabric
024	205448	Not Available	MOTOR, TIMER (120-60)
"	206886	<a href="#">12001906</a>	Timer
"	208222	<a href="#">12001906</a>	Timer
"	Y208602	Not Available	MOTOR, TIMER
025	NLA	Not Available	COVER, ENCLOSURE
026	203188	Not Available	TIMER ACCESS DOOR (WHT)
"	203188L	Not Available	ACCESS DOOR-ALMOND
"	203188M	Not Available	ACCESS DOOR-HARVEST WHEAT
027	207940	<a href="#">22001407</a>	Case, Coin Slide
"	207940L	<a href="#">22001408</a>	(ALM)
"	NLA	Not Available	(HWT)
028	<a href="#">214660</a>		Gasket, Control Center
029	NLA	Not Available	STRAP, MOUNTING
030	<a href="#">910309</a>		Washer, Mounting Strap
031	<a href="#">208044</a>		Harness, Wire
"	<a href="#">208045</a>		Harness, Wire Sensor Switch To Circuit Brd
"	NLA	Not Available	WIRE HARNESS

