


# Maytag MDE25PDAZWO 01 - TOP AND CONSOLE PARTS



Maytag [Commercial Maytag MDE25PDAZWO Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10135154		Not Available	Installation Instructions
"	W10239202		Not Available	TECH SHEET
"	<a href="#">W10335186</a>			PARTS LIST
2	<a href="#">W10137411</a>			Top
3	<a href="#">W10349748</a>			Harness, Main
4	<a href="#">W10137459</a>			Console
6	<a href="#">8565237</a>			Bracket, Console
11	3390647	<a href="#">488729</a>		Screw
12	<a href="#">W10137427</a>			Console
13	<a href="#">W10166385</a>			User-Interface Assembly
14	<a href="#">489136</a>			Screw, 3-24 X 1/32
16	<a href="#">W10188087</a>			Ground Wire Assembly
17	<a href="#">W10139046</a>			Nut 6-32
18	<a href="#">8565018</a>			Assembly, Hinge And Pin
19	342055	<a href="#">488627</a>		Screw
20	3347825	<a href="#">3353813</a>		Plate, Mounting

21	<a href="#">98445</a>	Screw, 10-16 X 3/4
22	<a href="#">W10137445</a>	Bracket - Top Panel, Left
23	3390647	<a href="#">488729</a> Screw
24	<a href="#">W10137444</a>	Bracket - Top Panel, Right
25	<a href="#">W10171128</a>	Meter Case
26	<a href="#">W10133245</a>	Dual Coin Drop Assembly
27	<a href="#">W10247389</a>	Sensor
"	<a href="#">W10247388</a>	Coin Optic Sensor Assembly Coin 2
28	<a href="#">W10142655</a>	Screw, 6-20 X 1.00
29	<a href="#">W10137319</a>	Hex-Bar Bolt
30	<a href="#">W10068270</a>	Washer, Lock
31	<a href="#">W10131838</a>	Switch, Vault And Service Door
32	<a href="#">W10133508</a>	Bracket, Service Switch
33	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
34	<a href="#">W10211244</a>	Wire, Harness Service Switch
35	<a href="#">3351136</a>	Service Door Assembly
36	<a href="#">W10166307</a>	Harness, Communication
37	<a href="#">W10166308</a>	Harness, Meter Case
40	<a href="#">W10137448</a>	Cushion, Meter Case
41	<a href="#">3353994</a>	Bolt, Meter Case Mounting
"	<a href="#">3349065</a>	Bolt, Meter Case Mounting
42	<a href="#">W10156125</a>	Cam-Lock
43	<a href="#">W10131113</a>	Push Button
44	<a href="#">W10334888</a>	Fascia-Console
45	<a href="#">W10137461</a>	Fascia-Dispenser
46	<a href="#">W10189313</a>	Inserts
47	<a href="#">488234</a>	Screw 8-32 X 1/4
48	<a href="#">W10187276</a>	Seal, Console
49	<a href="#">3373818</a>	Tab-Grounding
50	<a href="#">W10189075</a>	Washer, Brass
51	<a href="#">W10267645</a>	Cover, Display
52	<a href="#">W10137457</a>	Screw, 8-32 X 3/64
53	<a href="#">W10135255</a>	Assembly, Membrane Switch And Backer Plate

