

# Maytag MDG10CSEGL 04 - DOOR



Maytag [Commercial Maytag MDG10CSEGL Dryer Parts](#) Parts Diagram 04 - DOOR  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">Y314062</a>			Screw, Door Hinge And Panel
002	<a href="#">33001230</a>			Hinge, Door
003	<a href="#">33001240</a>			Door
"	33001257	<a href="#">33001240</a>		Door
004	<a href="#">33001241</a>			Handle, Door
"	33001254	<a href="#">37001047</a>		Handle, Door
005	<a href="#">33001131</a>			Seal, Door
006	33001132	<a href="#">33002342</a>		Plug, Sifft Hole
"	33001168		Not Available	PLUG, SIGHT HOLE (ALM)
007	Y304578	<a href="#">LA-1003</a>		Door Catch Kit
008	212982	<a href="#">22001650</a>		Fastener, Spring
009	<a href="#">Y310376</a>			Clip, Door Switch Harness
010	33001509	<a href="#">W10169313</a>		Switch-Dor
"	<a href="#">Y305753</a>	<a href="#">W10169313</a>		Switch-Dor
011	<a href="#">314937</a>			Seal, Front Panel
012	NLA		Not Available	SPEEDNUT, HINGE SCREW

"	NLA		Not Available	SCREW, PLASTIC
013	NLA		Not Available	PANEL, FRONT (WHT)
014	NLA		Not Available	PLUG, DOOR CATCH
015	<a href="#">33001175</a>			Cover, Hinge Hole
"	<a href="#">33001176</a>			Cover, Hinge Hole
016	<a href="#">Y313910</a>			Clip, Door Liner To Outer Panel
017	<a href="#">204439</a>			Screw And Fstner Assembly
018	33001243		Not Available	PANEL, INNER DOOR (W/SEAL)
019	314936	<a href="#">33001305</a>		Strike, Door
"	314944	<a href="#">33001305</a>		Strike, Door

**Howes**  
the laundry company®

**Howes**  
the laundry company®

**Howes**  
the laundry company®