


# Maytag MDG120P1HW 03 - FRONT PANEL/MAIN DOOR ASSEMBLIES



Maytag [Commercial Maytag MDG120P1HW Dryer Parts](#) Parts Diagram 03 - FRONT PANEL/MAIN DOOR ASSEMBLIES

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICAN DRYER CORP AT 508-678-9000
001	A820012	<a href="#">820012</a>		Ad-120 FRO
"	A820014		Not Available	PANEL, FRONT (RT HAND) (INCLUDES 1, 4 & 5..)
002	A150309	<a href="#">W10146761</a>		10-16 X 1
003	A150412		Not Available	SCREW, CRIMPTITE (PH.RD.HD.) (No.10-16 X 3/4" PH. RD. HD.)
004	A170340	<a href="#">170340</a>		3 1 2 SS
005	A154200	<a href="#">154200</a>		5 32 RIVE
006	A102308		Not Available	GASKET, DOOR (94" LNGT. ONLY)
007	A102210	<a href="#">102210</a>		20 7 16 D
"	A170730	<a href="#">170730</a>		10.3 Oz Cl
008	A150401	<a href="#">W10146762</a>		10-24 X 1
009	A306801	<a href="#">306801</a>		Wire Harness, Main

010	A102102	<a href="#">102102</a>	Door Magnet
011	A150309	<a href="#">W10146761</a>	10-16 X 1
012	A180150	<a href="#">180150</a>	35 Door H
013	A800122	<a href="#">W10146962</a>	100 Main
"	A800123	<a href="#">W10149264</a>	100 SS Ma
"	A800127	<a href="#">W10146963</a>	78 100 120
"	A800128	<a href="#">W10146964</a>	100 120 S
014	A150430	<a href="#">150430</a>	10 X 1 2
015	A180155	Not Available	BLOCK, DOOR HINGE (ONLY) (35" CROSS GRAY)

