


Maytag MDG120P1HW 04 - MAIN DOOR SWITCH ASSEMBLY



Maytag [Commercial Maytag MDG120P1HW Dryer Parts](#) Parts Diagram 04 - MAIN DOOR SWITCH ASSEMBLY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
000	W10124350		Not Available	ORDER PARTS FROM AMERICNA DRYER CORP AT 508-678-9000.
001	A102405	102405		Lg. Dryer
"	A821097	821097		Slotted Ma
"	A821098		Not Available	SWITCH, ASSEMBLY DOOR (COMPL.) (INCLUDES 1 - 4 & 6)
002	A150307			Screw, Crimptite
003	A102405	102405		Lg. Dryer
004	A137005	W10146741		SDS Door S
005	A121028	121028		1 4 X.032
006	A180155		Not Available	BLOCK, DOOR HINGE (ONLY) (35` CROSS GRAY)
007	A122705	122705		Umnl Sok 2
008	A122626	122626		15P Umnl C