


Maytag MDG12CSABW 03 - CABINET-REAR



Maytag [Commercial Maytag MDG12CSABW Dryer Parts](#) Parts Diagram 03 - CABINET-REAR
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y312905		Not Available	COVER, TERMINAL
002	33001284		Not Available	CORD, POWER
003	211881			Grommet, Cord Part Not Used- Gas Models Only
004	NLA		Not Available	SCREW & WASHER ASSEMBLY
005	216423	3370225		Screw
006	Y312951		Not Available	ACCESS COVER, BACK
007	204807			Ground Wire, Supp. Plte To Top Cover
"	Y305086			Adjustable Leg And Nut
008	Y314137			Foot, Rubber
009	Y052740	62739		Nut, Lock
010	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
011	213007			Xfor Cabinet See Cabinet, Back
012	NLA		Not Available	CABINET (WHT)

013

[Y313561](#)

Screw---NA

"

Y310632

[1163839](#)

Screw

014

[Y310376](#)

Clip, Door Switch Harness

015

[Y313561](#)

Screw---NA

