


# Maytag MDG12CSAGW 03 - CABINET-FRONT



Maytag [Commercial Maytag MDG12CSAGW Dryer Parts](#) Parts Diagram 03 - CABINET-FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	CONSOLE (WHT)
002	212276	<a href="#">W10116760</a>		Screw
003	33001703	<a href="#">33001740</a>		Cover, Top
004	33001486	<a href="#">98008544</a>		Screw
"	NLA		Not Available	PANEL, FRONT (WHT)---NA
005	<a href="#">33001241</a>			Handle, Door
006	<a href="#">214354</a>			Screw, Top Cover To Cabnt.
007	<a href="#">33001230</a>			Hinge, Door
008	<a href="#">22001496</a>			Front Panel Fastener And Screw
009	<a href="#">215075</a>			Fastener, Control Panel To Console
010	<a href="#">Y313561</a>			Screw---NA
"	Y310632	<a href="#">1163839</a>		Screw
011	Y303361		Not Available	BASE ASSY. (UPPER & LOWER)
012	<a href="#">Y314137</a>			Foot, Rubber

013	<a href="#">Y305086</a>		Adjustable Leg And Nut
014	<a href="#">Y052740</a>	<a href="#">62739</a>	Nut, Lock
015	<a href="#">213007</a>		Xfor Cabinet See Cabinet, Back
016	NLA		Not Available
017	210186	<a href="#">3370225</a>	CABINET (WHT) Screw
018	33001614		Not Available PLUG, FRONT PANEL (WHT)

