


# Maytag MDG12PDBBW 02 - CONTROL CENTER



\* CONTACT YOUR COMMERCIAL LAUNDRY DISTRIBUTOR

Maytag [Commercial Maytag MDG12PDBBW Dryer Parts](#) Parts Diagram 02 - CONTROL CENTER  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	22001871		Not Available	VAULT, COIN (WHT)
"	22001872	<a href="#">22002885</a>		Vault, Coin
002	22001810		Not Available	STRAP, MOUNTING
003	<a href="#">211294</a>	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
004	<a href="#">910309</a>			Washer, Mounting Strap
005	<a href="#">22001870</a>			Gasket, Coin Vault
"	<a href="#">22001874</a>			Gasket, Coin Vault
006	<a href="#">Y052740</a>	<a href="#">62739</a>		Nut, Lock
007	<a href="#">213035</a>			Bolt, Locking
008	<a href="#">910181</a>			Lockwasher, Terminal Block
009	NLA		Not Available	CAM, LOCKING
010	<a href="#">33001250</a>			Switch, Vault And Service Door
"	912012	<a href="#">3400409</a>		Screw
011	22001873	<a href="#">22004112</a>		Coin Drop Greenwald Us.25
"	<a href="#">22001875</a>			Coin Drop Assembly-Dual

"	<a href="#">22002144</a>	Single Faceplate	
012	<a href="#">216200</a>	Face Plate Return Button	
013	22001910	<a href="#">22003679</a>	Timer Access Door Assembly
"	22001911	<a href="#">22003692</a>	Timer Access Door Assembly
014	<a href="#">22001965</a>	Optic Switch Assembly	
015	<a href="#">314665</a>	Screw, Switch Assembly	
016	<a href="#">216068</a>	Screw, Coin Drop	
017	<a href="#">22001404</a>	Bracket, Service Switch	
018	212276	<a href="#">W10116760</a>	Screw
019	<a href="#">22001966</a>	Harness, Sensor Switch	
020	<a href="#">22002144</a>	Single Faceplate	

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>