


# Maytag MDG13CSAGW 03 - FRONT



Maytag [Commercial Maytag MDG13CSAGW Dryer Parts](#) Parts Diagram 03 - FRONT  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	COVER, TOP (WHT)
002	NLA		Not Available	PLATE, COVER
003	NLA		Not Available	CABINET (UPR-ALM)
004	306530		Not Available	BASE ASSEMBLY (LOWER)
005	910768	<a href="#">M0280301</a>		Tie Electr
006	<a href="#">33001302</a>			(WHT)
"	911050	<a href="#">4312464</a>		Screw
"	NLA		Not Available	SPACER ASSEMBLY (ALM)
"	Y310632	<a href="#">1163839</a>		Screw
007	NLA		Not Available	CABINET (LWR-ALM)
008	Y302699	<a href="#">22003428</a>		Leg, Adjustable
009	<a href="#">210684</a>			Foot, Adjustable Leg
010	<a href="#">210385</a>			Lock Nut For Adjustable Leg
011	314663	<a href="#">214354</a>		Screw, Top Cover To Cabnt.
012	33001486	<a href="#">98008544</a>		Screw
"	NLA		Not Available	PANEL, FRONT (WHT)---NA

013	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
014	33001203		Not Available	PANEL, CLEAR INNER (W/SEAL)
015	<a href="#">314939</a>			Handle, Door
"	<a href="#">314974</a>			Handle, Door
016	314967		Not Available	DOOR W/WINDOW OUTER HALF (WHT)
"	NLA		Not Available	(ALM)
017	33001711	<a href="#">33002936</a>		Medallion-
018	<a href="#">Y313559</a>			Screw
019	<a href="#">213007</a>			Xfor Cabinet See Cabinet, Back
020	<a href="#">22001496</a>			Front Panel Fastener And Screw
021	310933	<a href="#">33002194</a>		Nut, Speed

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>