


Maytag MDG13CSAKL 03 - FRONT



Maytag Commercial Maytag MDG13CSAKL Dryer Parts Parts Diagram 03 - FRONT
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	NLA		Not Available	COVER, TOP (ALM)---NA
002	NLA		Not Available	PLATE, COVER
003	NLA		Not Available	CABINET (UPR-ALM)
004	306530		Not Available	BASE ASSEMBLY (LOWER)
005	910768	M0280301		Tie Electr
006	911050	4312464		Screw
"	NLA		Not Available	SPACER ASSEMBLY (ALM)
"	Y310632	1163839		Screw
007	NLA		Not Available	CABINET (LWR-ALM)
008	Y302699	22003428		Leg, Adjustable
009	210684			Foot, Adjustable Leg
010	210385			Lock Nut For Adjustable Leg
011	314663	214354		Screw, Top Cover To Cabnt.
012	33001486	98008544		Screw
"	NLA		Not Available	PANEL, FRONT (ALM)---NA
013	211168	W10139210		Screw, 8-18 X 5/16

014	33001203	Not Available	PANEL, CLEAR INNER (W/SEAL)
015	314974		Handle, Door
016	NLA	Not Available	PANEL, OUTER (ALM)
017	33001711	33002936	Medallion-
018	Y313559		Screw
019	213007		Xfor Cabinet See Cabinet, Back
020	22001496		Front Panel Fastener And Screw
021	310933	33002194	Nut, Speed

