


# Maytag MDG17PDAXW2 02 - CABINET PARTS



Maytag [Commercial Maytag MDG17PDAXW2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">3391943</a>			Boot, Foot
2	<a href="#">356674</a>			Cone, Wedge
3	<a href="#">3400077</a>			Screw, 10-16 X 1/2
4	<a href="#">3391846</a>			Clip, Front Panel
5	<a href="#">8564010</a>			Assembly, Switch And Actuator
6	697773	<a href="#">3395530</a>		Screw
7	<a href="#">8310656</a>			Cabinet
8	3392100	<a href="#">49621</a>		Feet-Leveling
NI	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	<a href="#">49252</a>			Plug, Multivalent
13	<a href="#">W10344192</a>			Idler Assembly
14	3391915	<a href="#">681615</a>		Screw

15	<a href="#">3394331</a>		Plate Cover
16	<a href="#">W10167613</a>		Wire, Belt Switch
17	<a href="#">693152</a>		Bumper, Console
19	<a href="#">W10291934</a>		Clip
21	<a href="#">W10279703</a>		Hinge And Pin Assembly
22	<a href="#">W10116360</a>		Handle, Door
23	3390663	<a href="#">681414</a>	Screw, 10AB X 1/2
24	<a href="#">90406</a>		Cage Nut, 5/16-18
25	3390647	<a href="#">488729</a>	Screw
27	<a href="#">W10139766</a>	<a href="#">W10396034</a>	Motor Assembly 60 Hz
28	<a href="#">3387561</a>		Clamp-Pipe
29	3394341	<a href="#">W10299847</a>	Pulley-Motor
30	<a href="#">W10131172</a>		Belt, Drive
31	<a href="#">3390902</a>		Clip, Door Hinge
32	<a href="#">W10135695</a>		Bracket, Motor
33	3392186	<a href="#">4159590</a>	Washer
34	<a href="#">3393909</a>		Screw, 8-32 X 7/8
35	686590	<a href="#">279311</a>	Ignitor
36	W10440461	<a href="#">3401402</a>	Cord, Power
37	<a href="#">3387057</a>		Screw, 10-16 X 1/2 Orifice, Burner
38	<a href="#">8564011</a>		Bracket-Switch
40	<a href="#">W10155571</a>		Switch, Assembly
41	3406109	<a href="#">3406107</a>	Door Switch Assembly
42	<a href="#">W10002600</a>		Screw, 6-20 X 1 1/4
43	697215	<a href="#">3406797</a>	Toe Panel
44	<a href="#">3387242</a>		Seal, Front Panel
45	342055	<a href="#">488627</a>	Screw
46	<a href="#">3388229</a>		Retainer, Toe Panel
47	<a href="#">W10323061</a>		Door, Rear
48	<a href="#">694091</a>		Trim, Side Right Hand
49	<a href="#">W10322546</a>		Door, Front
50	<a href="#">8539892</a>		Wire-Motor To Belt Switch
51	W10192882	<a href="#">W10242810</a>	Panel
52	696144	<a href="#">279570</a>	Latch
53	8533974	<a href="#">4331106</a>	Screw, No.10-32 X 7/16
54	3392538	<a href="#">279570</a>	Latch
55	279731	<a href="#">49026</a>	4" - 90° Elbow
56	<a href="#">3390735</a>		Seal, Door
57	W10400668	<a href="#">W10492508</a>	Burner-Gas
58	<a href="#">W10299939</a>		Valve, Gas 60 Hz
59	<a href="#">345670</a>		Lock, Top
61	<a href="#">3405160</a>		Belt, Drive
62	<a href="#">W10212660</a>		Pad, Sound Dampening
63	<a href="#">W10191265</a>		Plug, Hinge Screw Front Panel
64	<a href="#">8529757</a>		Bracket, Burner
65	<a href="#">693995</a>		Screw, Hex Head
66	<a href="#">3393657</a>		Restrainer, Belt
NI	279818	<a href="#">W10470674</a>	Dryer Exhaust Kit