


Maytag MDG17PRAWW1 01 - TOP AND CONSOLE PARTS



Maytag [Commercial Maytag MDG17PRAWW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10184578		Not Available	INSTRUCTIONS INSTALLATION
"	W10135291		Not Available	Card Reader Installation Instructions
"	W10183571		Not Available	Tech Sheet
"	W10143804			Wiring Diagram
"	W10184592			Repair Parts List
2	W10137769			Cover, Card Reader
3	W10131114			Cover, Display
4	W10135182			Facia / Overlay
5	W10131119			Screw, 8-18 X 5/16
6	W10142728	3370225		Screw
7	W10137322			Screw, 6-20 X 1.00
8	W10140652			Screw, 6-20 X 1/2
9	W10124215			Bracket, Control
10	W10131113			Push Button
11	W10133515			Deflector Switch Assembly

12	W10161476		Shield, Probing
13	W10135233		Push Button And Switch Assembly
14	W10130081		Control Board
15	W10139046		Nut 6-32
16	W10133282		Switch, Jumper Service Vault
17	W10137770		Retainer, Card Reader Cover
18	3400618		Screw, 6-19 X 3/8
19	W10133514		Spacer
20	W10205150	W10235158	Console
21	W10131123		NUt, 8 U-Type
22	W10139210		Screw, 8-18 X 5/16
31	3390647	488729	Screw
32	8317340		Cover, Terminal Block
33	3390814	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
34	W10177312		Panel, Rear
35	8533971	90767	Screw, 8A X 3/8 HeX Washer Head Tapping
36	W10131839		Transformer 120 To 22.5 Vac
37	3400000		Screw, 10-24 X 3/8
38	W10130190		Harness, Main
39	W10136704		Top
40	W10133304		Harness, Wiring Card Reader
41	W10143462		Screw, 6-32 X 9/16
42	W10131115		Bezel
43	8540229	W10339736	Filter, Interference
44	W10175650		Jumper-Line Filter
45	W10135255		Assembly, Membrane Switch And Backer Plate

