


Maytag MDG25PDAXW0 01 - TOP AND CONSOLE PARTS



Maytag [Commercial Maytag MDG25PDAXW0 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10135154		Not Available	Installation Instructions
"	W10239202		Not Available	TECH SHEET
"	W10335189			PARTS LIST
2	W10137411			Top
3	W10337045			Harness, Main
4	W10137459			Console
6	8565237			Bracket, Console
11	3390647	488729		Screw
12	W10137427			Console
13	W10166385			User-Interface Assembly
14	489136			Screw, 3-24 X 1/32
16	W10188087			Ground Wire Assembly
17	W10139046			Nut 6-32
18	8565018			Assembly, Hinge And Pin
19	342055	488627		Screw
20	3347825	3353813		Plate, Mounting

21	98445	Screw, 10-16 X 3/4
22	W10137445	Bracket - Top Panel, Left
23	3390647	488729 Screw
24	W10137444	Bracket - Top Panel, Right
25	W10171128	Meter Case
26	W10133245	Dual Coin Drop Assembly
27	W10247389	Sensor
"	W10247388	Coin Optic Sensor Assembly Coin 2
28	W10142655	Screw, 6-20 X 1.00
29	W10137319	Hex-Bar Bolt
30	W10068270	Washer, Lock
31	W10131838	Switch, Vault And Service Door
32	W10133508	Bracket, Service Switch
33	W10139210	Screw, 8-18 X 5/16
34	W10211244	Wire, Harness Service Switch
35	3351136	Service Door Assembly
36	W10166307	Harness, Communication
37	W10166308	Harness, Meter Case
40	W10137448	Cushion, Meter Case
41	3353994	Bolt, Meter Case Mounting
"	3349065	Bolt, Meter Case Mounting
42	W10156125	Cam-Lock
43	W10131113	Push Button
44	W10334888	Fascia-Console
45	W10137461	Fascia-Dispenser
46	W10189313	Inserts
47	488234	Screw 8-32 X 1/4
48	W10187276	Seal, Console
49	3373818	Tab-Grounding
50	W10189075	Washer, Brass
51	W10267645	Cover, Display
52	W10137457	Screw, 8-32 X 3/64
53	W10135255	Assembly, Membrane Switch And Backer Plate

