


Maytag MDG25PRAWW1 01 - TOP AND CONSOLE PARTS



Maytag [Commercial Maytag MDG25PRAWW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10135154		Not Available	Installation Instructions
"	W10313706		Not Available	INSTALLATION INSTRUCTIONS, CARD READER
"	W10239202		Not Available	TECH SHEET
"	W10469603		Not Available	PARTS LIST
2	W10137410			Top
3	W10337045			Harness, Main
4	W10137459			Console
6	8565237			Bracket, Console
11	3390647	488729		Screw
12	W10137427			Console
13	W10166387			User-Interface Assembly
14	489136			Screw, 3-24 X 1/32
16	W10188087			Ground Wire Assembly
17	W10139046			Nut 6-32
18	8565018			Assembly, Hinge And Pin

19	342055	488627	Screw
20	W10135255		Assembly, Membrane Switch And Backer Plate
21	W10137461		Fascia-Dispenser
22	W10137445		Bracket - Top Panel, Left
23	3390647	488729	Screw
24	W10137444		Bracket - Top Panel, Right
25	W10137457		Screw, 8-32 X 3/64
26	W10137454		Bezel, Card Reader
27	W10331020		Harness, Wiring Card Reader
28	W10267645		Cover, Display
29	W10189075		Washer, Brass
30	3373818		Tab-Grounding
31	W10187276		Seal, Console
32	488234		Screw 8-32 X 1/4
33	W10213906		Cover, Card Reader
34	W10334889		Fascia-Console
35	W10131113		Push Button
36	W10166307		Harness, Communication
37	W10189313		Inserts
40	W10133282		Switch, Jumper Service Vault
41	W10344080		Card Reader, Conversion Kit Vault Switch

