


# Maytag MDG26CSABW 04 - CS CONTROL CENTER



14

Maytag [Commercial Maytag MDG26CSABW Dryer Parts](#) Parts Diagram 04 - CS CONTROL CENTER  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	203188		Not Available	TIMER ACCESS DOOR (WHT)
"	203188L		Not Available	ACCESS DOOR-ALMOND
"	203188M		Not Available	ACCESS DOOR-HARVEST WHEAT
002	213750	<a href="#">W10133266</a>		Cam-Lock
003	211168	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
004	<a href="#">314335</a>			Peg, Tine Adjustment
005	<a href="#">314331</a>			Spring, Torsion Return
006	<a href="#">Y312270</a>			Clip, Spring Retainer
007	<a href="#">211065</a>			Spring, Index Wheel
008	314337	<a href="#">33002968</a>		Slider
009	<a href="#">211790</a>			Lock Ring For Timer Shaft
010	<a href="#">306104</a>			Actuator Switch Kit
011	NLA		Not Available	HELICAL SPRING ----N
012	314337	<a href="#">33002968</a>		Slider
013	<a href="#">Y052721</a>			Nut, Terminal Block Plate

014	<a href="#">910387</a>		Lockwasher, Vault Assembly
015	Y052634	<a href="#">701719</a>	Nut, Hex
016	<a href="#">215559</a>		Bolt, Coin Slide Locking
017	<a href="#">314339</a>		Switch And Slider Bracket
018	<a href="#">314332</a>		Spring, Actuator
019	305798	Not Available	BYPASS SWITCH FOR MOTOR
020	<a href="#">Y305799</a>		Bypass Switch For Heater
021	910708	<a href="#">488234</a>	Screw 8-32 X 1/4
022	NLA	Not Available	SCREW
023	<a href="#">314333</a>		Timer Mounting Bracket
024	NLA	Not Available	INSTRUCTION LABEL
025	<a href="#">305796</a>		Timer
026	<a href="#">305813</a>		Part Not Available Part Not Used
027	<a href="#">305800</a>		Wire Harness For Timer
028	<a href="#">305870</a>		Timer Motor
029	<a href="#">305797</a>		Torsion Timer Assembly Complete
030	212707	<a href="#">3196385</a>	Screw
031	<a href="#">314334</a>		Bracket For Coin Slide
032	206956	<a href="#">22001405</a>	Case, Coin Slide
"	206956L	<a href="#">22001405</a>	Case, Coin Slide
"	206956M	<a href="#">22001405</a>	Case, Coin Slide
033	<a href="#">214660</a>		Gasket, Control Center
034	NLA	Not Available	STOP, TIMER MECHANISM
035	NLA	Not Available	MTG. STRAP---NA
036	<a href="#">910309</a>		Washer, Mounting Strap
037	<a href="#">211294</a>	<a href="#">90767</a>	Screw, 8A X 3/8 HeX Washer Head Tapping
038	205423	<a href="#">208883</a>	Coin Box K
"	205423L	<a href="#">208883</a>	Coin Box K
"	205423M	<a href="#">208883</a>	Coin Box K
039	212328	<a href="#">W10139762</a>	Hex Nut, 3/4-27
040	<a href="#">Y052740</a>	<a href="#">62739</a>	Nut, Lock
041	<a href="#">214648</a>		Decal, Coinage
042	314547	<a href="#">Y308109</a>	Slide And Adj. Return Bracket
043	<a href="#">314546</a>		Wheel, Index
044	314548	<a href="#">33002967</a>	Actuator, Switch

